




Series 6000 Inside Mount Parts Explosion



Series 6000 Inside Mount PARTS LIST	
R5120	Drawbar
R5161	Screen Tube
R5170	Spring Roller
R5190	Closer
D2160	Strike
R5467	Toggle & Handle
R5468	Double Hook Latch
R6010	Housing
R6020	Housing Track
R6040	Top / Bottom Track
R6047	Head Track
R6070	PVC Cushion
R6110	Canopy End Cap - LH
R6100	Canopy End Cap - RH
R6160	Bushing
R6171L	Drawbar End Cap Assembly - LH
R6171R	Drawbar End Cap Assembly - RH

R. Lang Company
 Richmond - Sacramento - Visalia
 Phone 800-677-5264 Fax 888-526-4329